CABINET PARTS

REFRIGERATOR

For Models: ET18GKXHW00, ET18GKXHN00, ET18GKXHT00
(White) (Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ET18GKXHW00, ET18GKXHN00, ET18GKXHT00
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT2201079	Service & Wiring Sheet
	LIT2205478	Energy Label
	LIT2200940	Use & Care Guide

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

	LIT677969	Do−It−Yourself Manual, Ref./Fzr.
	LIT677971	Do−It−Yourself Manual, Icemaker
2	2189410	Hinge (Top)
3	2166108	Roller−Front (2)
5	489385	Clamp, Tube (Water Supply Line)
6	3400504	Screw
7	2179826	Rivet
12	549193	Clamp−Cord
15	489497	Screw
16	2183972	Hinge, Center
17	2183854	Shim, Hinge Center
18	3400881	Screw
20	2189194	Hinge Butt
21	487576	Washer
23	2172743	Shim, Bottom Hinge
24		Fitting, Water Tube (Not Serviced)
27		Hole Plug (6)
	2201012	White
	2201013	Almond
	2200924	Biscuit
28		Seal, Front (Not Serviced)
30		Seal, Rear (Not Serviced)
35		Corner Filler (2)
	2201014	White
	2201015	Almond
	2200926	Biscuit
36		Grille
	2201009	White
	2201010	Almond
	2201021	Biscuit
38	489341	Washer
39	2189356	Clip−Grille
40		Cover−Hinge
	2160403	White
	2160404	Almond
	2200937	Biscuit
41		Rail, Center (Not Serviced)
44	2189475	Cover, Unit
45		Cabinet (Not a Serviceable Part)

DOOR PARTS

For Models: ET18GKXHW00, ET18GKXHN00, ET18GKXHT00
(White) (Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Models: ET18GKXHW00, ET18GKXHN00, ET18GKXHT00
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #9 & #22)
	2183948	White
	2183949	Almond
	2205285	Biscuit
5		Handle Center
	2202807W	White
	2202807N	Almond
	2202807T	Biscuit
6	489357	Screw
8	8281146	Screw
9		Door Gasket, Magnetic
	2159057	Mist Beige
11	2201051	Trim, Door Shelf
12		Cover, Screw
	2202819W	White
	2202819N	Almond
	2202819T	Biscuit
13		Nameplate
	2175383	White Model
	2175384	Almond Model
	2205769	Biscuit
14	2195943	Trim, Door Shelf
16	2180027	Trim, Door Shelf
17	489028	Screw
18	2201052	Trim, Door
19		Freezer Door (Includes #22 & #23)
	2182487	White
	2182491	Almond
	2205279	Biscuit
20		Hole Plug
	2189000	White
	2189008	Almond
	2200936	Biscuit
22	2183003	Thimble
23		Door Gasket, Magnetic
	2159327	Mist Beige
24	2195915	Endcap, Trim
25	2156003	Endcap, Trim
26	2189202	Bracket, Door Stop (2)
27	488921	Screw
28		Hole Plug
	844478	White
	989196	Almond
	2200934	Biscuit
29	2156007	Plug−Trim
30	2156006	Plug−Trim
31	2171036	Compartment Door
33		Handle, F.C.
	2202806W	White
	2202806N	Almond
	2202806T	Biscuit
37	2201050	Trim−Door (2)
42	2195949	Trim, Door

LINER PARTS

For Models: ET18GKXHW00, ET18GKXHN00, ET18GKXHT00
(White) (Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LINER PARTS

For Models: ET18GKXHW00, ET18GKXHN00, ET18GKXHT00
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	531933	Grommet (2)
3	2189268	Gasket, Evaporator Cover (Side)
4	2199008	Timer, Defrost
6	941839	Hole Plug
7	2200632	Wire Assy. Control Box
8	2162085	Socket, Light (2)
9	2179858	Damper, Air
10	2183448	Fan Motor
11	2163777	Fan Blade
12	2200820	Control Box
13	2200830	Thermostat Assy. (Includes Items 5, 18 & 36)
14	489478	Screw
15	489412	Screw
16	2183154	Cover−Evaporator
17	527949	Light Bulb (2)
18	2200831	Weight, Thermal
19	1118894	Rocker Arm Switch
20	2179859	Post, Damper
21	2176281	Cover, Air Diffuser
22	2200863	Knob, Thermostat
23	2182340	Air Tower
24	2189452	Air Diffuser, Bottom
25	2172565	Freezer Floor
26	2200793	Air Diffuser, Top
27	2190688	Cover, Hole
28	940014	Hole Plug
29	2200641	Bracket, Fan Motor
30	2189267	Gasket, Evaporator Cover (Top)
32	487996	Cap
33	2176341	Clip, Defrost Timer
34	2176297	Knob, Damper
35	2163810	Bracket, Damper Knob
36	2205079	Seal, Rear Thermostat
38	2171931	Release Valve
39	2200630	Wire Assembly,F.C.

UNIT PARTS

For Models: ET18GKXHW00, ET18GKXHN00, ET18GKXHT00
(White) (Almond) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ET18GKXHW00, ET18GKXHN00, ET18GKXHT00
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	2201161	Plate, Unit Mounting
2	489478	Screw
3	2183849	Condenser
4	2176300	Heater, Defrost
5	2195391	Evaporator Assy.
6	489494	Screw
7	2172619	Drain Pan
8	2182380	Defrost Bi−Metal
9	2176301	Bracket, Heater
10	2163780	Extension, Air Baffle
11	2201184	Support Block
12		Cover
	2162358	Production
	2162358	Service
13		Overload
	2183452	Production (Includes Relay)
	4387938	Service (Includes Relay)
14		Grommet (4)
	1100826	Production
	4387558	Service
15		Relay
	2176740	Production (Service See Overload)
16	489373	Screw
17	2150304	Roller (2)
18	981126	Rivet
19	2182338	Clip, Heater
21		Nut (Not Serviced)
28	2196771	Compressor (Includes Items 12, 13, 15, 29) (Also Order 482801 Installation Kit & 876765 Tube Kit)
29	2199167	Drier
30	2155774	Clamp
39	2198921	Air Baffle
40	2183437	Motor, Condenser
42	2199117	Wire Assy. Unit
43	2190685	Fan Blade
44	486692	Nut
46	2179722	Tube, Discharge
47	2189161	Tube, Suction
48	2194319	Tube, Process
49	2174670	Tube, Condenser To Heat Loop
57	489462	Screw
58	2163795	Evap. Tray

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated and Optional Parts Not Included

	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")
	482278	Start Kit

REFRIGERANT CHARGE

3.75 Ozs.
(R134A)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: ET18GKXHW00, ET18GKXHN00, ET18GKXHT00
(White) (Almond) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	2202822	Shelf, Ladder (2)
2	2202821	Shelf, Ladder Center
3	2177824	Glass, Full Shelf
4	2163835	Track, Crisper
5	489478	Screw
6	2163762	Cup, Shelf Mounting
7	2201101	Shelf, Cantilever
8	2201097	Trim, Shelf
9	2195342	Cover, Crisper
10	2182730	Egg Bin
11	2169921	Insert, Crisper Cover
12	2201105	Shelf, Meat Pan Cantilever
14	2169917	Glass, Meat Cover
15	2172541	Crisper Support
16	2201103	Shelf, Full Cantilever
17	2189453	Shelf, Freezer
18	2193394	Trim, Shelf Rear
19	2201022	Pan, Crisper
20	2201031K	Pan, Meat
21	2201135	Trim, Shelf Front
22	841180	Ice Tray
24	2201023	Pan, Crisper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: ET18GKXHW00, ET18GKXHN00, ET18GKXHT00
(White) (Almond) (Biscuit)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Miscellaneous

PARTS NOT ILLUSTRATED

978941	Insulation, Fiberglass (63−1/2" x 35−1/2" x 2−5/8")
212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4" x 108")
876305	Kit, Insulation (14 Pcs. 3" x 24" x 48")
876370	Kit, Insulation (2 Pcs. 3" x 24 " x 48")
876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
505587	Sealer, Mastic (1 Qt.)
511873	Touch−Up, White Porcelain (2 Oz.)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1−1/4 Oz.)
606755	Bag, Insulation (36−5/8" x 46")
799833	Kit, Evaporator Repair (Aluminum Epoxy)
799832	Kit, Porcelain Repair (White)
503695	Cork Sealer (1/4 Pound)

Customer Touch−Up Material

*350942	Primer, White (13 Oz. Spray Can)
*350930	Enamel, White (13 Oz. Spray Can)
*350956	Enamel, Almond (13 Oz. Spray Can)
*4392901	Enamel, Biscuit (13 Oz. Spray Can)
72017	Brush Touch−Up Kit (White)
72107	Brush Touch−Up Kit (Almond)
4392899	Brush Touch−Up Kit (Biscuit)

Refinishing Material

799344	Enamel, White (1 Qt. Uncut)
978883	Enamel, Almond (1 Qt. Uncut)
4392900	Enamel, Biscuit (1 Qt. Uncut)
833938	Kit, Terminal Connector

* **CAUTION:** The spray paint is not to be used where the paint may make contact with the door gaskets.

ICE MAKER FIELD INSTALLABLE

ECKMF94

TORX SCREW WRENCH

1117510 Torx Key